









USE 84 GROWNET WITH 4 DOTS AS SHOWN BELOW WHICH IS SUPPLIED W/BACKSHELL



STRIP INSULATION BACK 1/4' TO 5/16'



XX (DECIMETER) X .328 = FT. STARTING LENTH = XX FT + 1.25 FT. BDM VALUE = STARTING LENGTH + 1 FT.

## CONFIGURED CABLE PROCEDURE:

THE PURPOSE OF THIS DRAWING IS TO DEFINE VARIOUS BACKSHELL AND SCREWLOCK TYPES AS REQUIRED BY THE SHOP TRAVELLER.

- 1.) LIDCATE THE SHOP TRAVELLER FOR CABLE TO BE MANUFACTURED.
  2.) USING SHOP TRAVELLER AND TERMINATION CHART AT RIGHT—
  3.) DETERMINE CABLE "LOURITH TERMINATION.
  b.) DETERMINE "ADDITOR END" TERMINATION.
  J.) USING "THE ABOVE INFORMATION, MANUFACTURE CABLE WITH APPROPRIATE TERMINATIONS.
  5.) LABEL CABLE WITH NEV CONFIGURED PART NUMBER PER NOTE 4.
  FOLLOWING THE "CONFIGURED PART NUMBER DEFINITION" SHOWN AT FARR RIGHT.

## TERMINATION CHART



